



- NOTES:
1. SIDE MOUNTED THERMOSTAT LOCATIONS ARE TYPICAL FOR BOTH SIDES
  2. REMOVE TILE-RING BEFORE APPLYING DRYWALL ON UNITS WITH REMOTE MOUNTED THERMOSTAT
  3. STANDARD THERMOSTAT MOUNTING LOCATION WITH "ADA" OPTION IS ON UNIT RETURN WALL PANEL AS SHOWN. SEE DRAWING FCS05-KV10.

Revision Date: 04/15	Form: FCS05-KVPH03	Replaces: NEW
----------------------	--------------------	---------------