



SIZE	EHB	HEM	HFM HPM VFM	MCM SCM VCM FCM
02	20	21	28	31
	[508]	[533]	[711]	[787]
03	20	26	34	38
	[508]	[660]	[864]	[965]
04	20	26	42	46
	[508]	[660]	[1067]	[1168]
06	24	22	42	46
	[610]	[559]	[1067]	[1168]
08	24	26	46	49-1/2
	[610]	[660]	[1168]	[1257]
10	24	22	56	59-1/2
	[610]	[559]	[1422]	[1511]
12	32	30	64	67
	[813]	[762]	[1626]	[1702]
14	32	36	68	70-1/2
	[813]	[914]	[1727]	[1791]
17	32	36	80	82
	[813]	[914]	[2032]	[2083]

**NOTES:**

1. ALL DIMENSIONS ARE INCHES [MM]
2. ALL DIMENSIONS ARE  $\pm 1/8"$  [3]
3. METRIC VALUES ARE SOFT CONVERSION
4. CLEARANCE SHOWN FOR INTERNAL COMPONENT ACCESS/REMOVAL; REFER TO APPROPRIATE LOCAL AND NATIONAL CODES FOR ANY ADDITIONAL REQUIREMENTS
5. DIMENSIONS ARE MINIMUM; SITE CONDITIONS OR FIELD INSTALLED COMPONENTS MAY REQUIRE ADDITIONAL CLEARANCE

Revision Date: 12/14	Form: AHMS01-KBM02	Replaces: NEW
----------------------	--------------------	---------------